

# TEKMMOTION REAL GLASS SCREEN SHIELD

## INSTALLATION

Be sure to read the user manual before applying

①



Be sure to clean the phone screen (dust, oil and etc.) Before applying to avoid bad adhesion.

②



Peel off blue marked ② film, stick it on the phone screen and remove bubbles with a credit card.

③



Peel off this film to remove the dust on the screen. Use a light to check if needed.

④



Use blue marked ② film to remove dust if needed.

⑤



Peel off red marked ① film, align it to the four edges of the phone screen.

Slightly push the protector center to begin adhesion. Squeeze bubbles from center to the edge if needed.

⑥



HOME BUTTON COVER INSTALLATION

⑦



## REMOVAL



Lift any corner of the protector horizontally along the wide side slowly, do not touch adhesive layer at the back.

## REINSTALLATION



\*Slightly and slowly lift the corner near the bubble until bubble disappears, resume protector and it will be adhesive again.

\* Remove dust on the screen with provided film

## DEMONSTRATION



### ⚠ CAUTION

- \* Tempered glass shield is made from silicon dioxide. Shield may scratch if it contacts an object which is harder than glass.
- \* Red marked ① side has self-adhesive layer. Apply correct side during installation.
- \* Real Glass screen shield is NOT recommended for reuse.
- \* Keep away from children
- \* Limited warranty does not cover damages due to external causes.